

ASSEMBLY INSTRUCTION

MODEL : WWZ 13888 (BUTTON) DOUBLE DECKER BED - Metal Slat

Before you begin, please follow Assembly Instruction carefully. Follow them step by step.

<p>STEP 1</p> <p>(B) M6 X 20MM JCBC SCREW - 8 PCS</p> <p>(F) M4 ALLEN KEY - 1 PC</p>	<p>STEP 2</p> <p>(B) M6 X 20MM JCBC SCREW - 8 PCS</p> <p>(D) WOOD DOWEL M16 X 65MM - 4 PCS</p> <p>(F) M4 ALLEN KEY - 1 PC</p>
<p>STEP 3</p> <p>(A) M6 X 20MM JCBB SCREW - 8 PCS</p> <p>(B) M6 X 20MM JCBC SCREW - 6 PCS</p> <p>(C) M6 X 40MM JCBC SCREW - 1 PC</p> <p>(E) M6 HEX NUTS - 1 PC</p> <p>(F) M4 ALLEN KEY - 1 PC</p>	<p>STEP 4</p> <p>(A) M6 X 20MM JCBB SCREW - 8 PCS</p> <p>(F) M4 ALLEN KEY - 1 PC</p>

ASSEMBLY INSTRUCTION

MODEL : WWZ 13888 (BUTTON) DOUBLE DECKER BED - Metal Slat

Before you begin, please follow Assembly Instruction carefully. Follow them step by step.

<p>STEP 5</p> <p>(C) M6 X 40MM JCBC SCREW - 2 PCS</p> <p>(E) M6 HEX NUTS - 2 PCS</p> <p>(F) M4 ALLEN KEY - 1 PC</p>	<p>PART LIST</p> <table border="1"> <tr> <td>1 TOP POST X 4 PCS</td> <td>2 BOTTOM POST X 4 PCS</td> <td>5 STAIRCASE X 1 PC</td> </tr> <tr> <td>3 HEADBOARD / FOOTBOARD X 4 PCS</td> <td>6 LONG FENCING A X 1 PC</td> <td></td> </tr> <tr> <td>4 METAL BED BASE X 2 PCS</td> <td>7 LONG FENCING B X 1 PC</td> <td></td> </tr> </table>	1 TOP POST X 4 PCS	2 BOTTOM POST X 4 PCS	5 STAIRCASE X 1 PC	3 HEADBOARD / FOOTBOARD X 4 PCS	6 LONG FENCING A X 1 PC		4 METAL BED BASE X 2 PCS	7 LONG FENCING B X 1 PC	
1 TOP POST X 4 PCS	2 BOTTOM POST X 4 PCS	5 STAIRCASE X 1 PC								
3 HEADBOARD / FOOTBOARD X 4 PCS	6 LONG FENCING A X 1 PC									
4 METAL BED BASE X 2 PCS	7 LONG FENCING B X 1 PC									
<p>FULL SETUP</p>	<p>HARDWARE LIST</p> <table border="1"> <tr> <td>(A) M6 X 20MM JCBB SCREW - 16 PCS</td> <td>(D) WOOD DOWEL M16 X 65MM - 4 PCS</td> </tr> <tr> <td>(B) M6 X 20MM JCBC SCREW - 22 PCS</td> <td>(E) M6 HEX NUTS - 3 PCS</td> </tr> <tr> <td>(C) M6 X 40MM JCBC SCREW - 3 PCS</td> <td>(F) M4 ALLEN KEY - 1 PC</td> </tr> </table>	(A) M6 X 20MM JCBB SCREW - 16 PCS	(D) WOOD DOWEL M16 X 65MM - 4 PCS	(B) M6 X 20MM JCBC SCREW - 22 PCS	(E) M6 HEX NUTS - 3 PCS	(C) M6 X 40MM JCBC SCREW - 3 PCS	(F) M4 ALLEN KEY - 1 PC			
(A) M6 X 20MM JCBB SCREW - 16 PCS	(D) WOOD DOWEL M16 X 65MM - 4 PCS									
(B) M6 X 20MM JCBC SCREW - 22 PCS	(E) M6 HEX NUTS - 3 PCS									
(C) M6 X 40MM JCBC SCREW - 3 PCS	(F) M4 ALLEN KEY - 1 PC									