



















# S4 Flexy

		
20	20	300 MM. 2
		
4	50	7x 50 8
		
8 x 35 20	4	6,3 x 9,5 8
		
4	4 x 16 16	96 MM. 4
		
4 x 17,5 8	3,5 x 16 10	Плани за Фазер 2



No	Name	pc.	Cartoon	
1	Top	1	1/3	
2	Botton	1		
3	Left Side of drawer	2		
4	Right Side of drawer	2		
5	Botton of drawer	2		
6	Back of drawer	2		
7	Shelf	1		
8	Horizontal separation	1		
9	Left Side	1		2/3
10	Right Side	1		
11	Vertical separation	1		
12	Hardboard	2		
13	Front of drawer	2		
14	Door Big	1	3/3	
15	Door small	1		
16	Hardwear			

