

PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the uphols tery.







B:2PCS







D:1PC

G:4PCS




E:4PCS

0 M6*15 H:20PCS



I:1PC

Do not fully tighten bolts until assembly is complete.



Do not fully tighten bolts until assembly is complete.

