






WARRANTY & ASSEMBLY GUIDE





Read instruction carefully. Remove all the wrapping materials, staples and straps from the carton. Refer to the hardware and furniture parts list as a guidance. Make sure you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface such as carpet to prevent from scratches.


CAUTION:

KEEP ALL HARDWARE PARTS OUT OF REACH CHILDREN.

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	HEX COM SCREW 5/16" X 2 1/2" 	8 pcs
2	SPRING WASHER 5/16" 	8 pcs
3	FLAT WASHER 5/16" 	8 pcs
4	SPANNER 12.8 	1 pc

PARTS LIST		
ITEM	DESCRIPTION	QTY
A	TABLE TOP 	1 pc
B	TABLE LEG 	4 pcs

WARRANTY & ASSEMBLY GUIDE



STEP 1

