

ASSEMBLY INSTRUCTION







DESCRIPTION : TV CABINET

MODEL : TV 213482

SOFT DRY CLOTH	CHEMICAL	HEAT	KEEP DRY	HANDLE WITH CARE	DO NOT USE KNIFE	

HARDWARE		A	B	C	D	E	F	G	H
	WOOD DOVEL	16	WOOD SCREW	6	CSK CAP WOOD	1	MINIFIX (HOUSING)	4	HINGES 7/8
	M8 X 25MM	24	M5.5 X 18MM	6	NAIL 5/8	1	MINIFIX (EURO 24) CAP	4	2
							MINIFIX		
							(EURO 24)		
							MINIFIX		
							(EURO 24)		
							CAP		
							SQUARE LEG		

PART LIST





ASSEMBLY INSTRUCTION

DESCRIPTION : TV CABINET

MODEL : TV 213482



SOFT DRY CLOTH	CHEMICAL	HEAT	KEEP DRY	HANDLE WITH CARE	DO NOT USE KNIFE	

STEP 6





BOTTOM VIEW

STEP 7





STEP 8



BACK VIEW

STEP 9



COMPLETED

