





ZITA PLUS CARAMEL



PRODUCT DESCRIPTION

Read instruction carefully. Remove all wrapping material, Staples and straps from the carton. See Hardware and Furniture Part List for guidance. Be sure you have all parts before you start assembly. Place all wooden furniture part a clean and flat soft surface, such as carpet or rug to prevent from being scratched.

CAUTION :

KEEP ALL HARDWARE PART OUT OF REACH OF CHILDREN.

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC M6 X 45MM	6 PCS
2	SPRING WASHER 1/4"	6 PCS
3	CSK CB SCREW M4 X 32MM	5 PCS
4	ALLEN KEY (M4)	1 PC
5	BOLT SCREW WITH SPRING & FLAT WASHER	3 PCS
6	WRENCH	1 PC

PART LIST		
ITEM	DESCRIPTION	QTY
A	CHAIR BACK	1 PC
B	FRONT LEG	1 SET
C	BACK LEG	1 SET
D	SIDE FRAME	2 PCS
E	CHAIR SEAT	1 PC